

[20:29:12.064] << 4:010 S5:008 S6:000 S7:060 S8:000 S10:002 S18:001

[20:29:03.608] =====

[20:29:03.609] Поиск модема на порту COM5...

[20:29:03.612] =====

[20:29:03.615] Пробуем настройки порта: скорость "1200", бит данных: "8", четность: "Нет",
стоповых бит: "1".

[20:29:03.619] >> ATQ0

[20:29:04.008] << OK

[20:29:04.024] Модем обнаружен.

[20:29:04.036] >> AT+CSQ=?

[20:29:04.377] <<

[20:29:04.657] << +CSQ: (0-31,99),(0-7,99)

OK

[20:29:04.665] =====

[20:29:04.667] Идентификация модема...

[20:29:04.669] =====

[20:29:04.671] >> ATI

[20:29:05.342] << Cinterion

BGS2-E8

REVISION 01.301

OK

[20:29:05.347] >> ATI1

[20:29:06.196] << Cinterion

BGS2-E8

REVISION 01.301

A-REVISION 01.000.06

OK

[20:29:06.198] >> ATI3

[20:29:06.507] << OK

[20:29:06.514] >> AT+CGMI

[20:29:07.002] << Cinterion

OK

[20:29:07.009] >> AT+CGMM

[20:29:07.363] << BGS2-E8

OK

[20:29:07.370] >> AT+CGMR

[20:29:07.703] <<

[20:29:07.909] << REVISION 01.301

OK

[20:29:07.911] >> AT+CGSN

[20:29:08.450] << 358678064769483

OK

[20:29:08.456] >> AT+COPS=3,0

[20:29:08.852] << OK

[20:29:08.854] >> AT+COPS?

[20:29:09.458] << +COPS: 0,0,"beeline"

OK

[20:29:09.469] >> AT+CPIN?

[20:29:10.002] << +CPIN: READY

OK

[20:29:10.009] >> AT+CREG?

[20:29:10.375] << +CREG: 0,1

OK

[20:29:10.377] >> AT+CSQ

[20:29:10.699] << +CSQ: 29,99

OK

[20:29:10.701] =====

[20:29:10.703] Получение текущих настроек модема...

[20:29:10.704] =====

[20:29:10.706] >> AT&V

[20:29:11.536] << ACTIVE PROFILE:

E0 Q0 V1 X4 &C1 &D2 &S0 \Q0

S0:000 S3:013 S

[20:29:11.968] Подключенное устройство не является модемом и не может быть настроено при помощи утилиты.

[20:29:12.064] << 4:010 S5:008 S6:000 S7:060 S8:000 S10:002 S18:001

+CBST: 0,0,1

[20:29:12.605] << +CRLP: 61,61,78,6

+CR: 0

+FCLASS: 0

+CRC: 0

+CMGF: 0

[20:29:13.134] << +CNMI: 0,0,0,0,1

+ICF: 3

+ILRR: 0

+IPR: 1200

+CMEE: 0

^SMGO

[20:29:13.676] << : 0,0

+CSMS: 0,1,1,1

^SACM: 0,"000000","000000"

^SLCC: 0

^SC

[20:29:14.202] << KS: 0,1

^SSET: 0

+CREG: 0,1

+CLIP: 0,2

+CAOC: 0

+COPS: 0,0,

[20:29:14.449] << "beeline"

+CGSMS: 3

OK